




Canon Powershot A70 Rear Exterior Panel Replacement

Written By: Shalan Ertis



INTRODUCTION

This guide explains the location of exterior screws and the process to remove the rear panel.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Rear Exterior Panel




- Remove Wrist strap
- Unscrew the three small screws on the bottom

Step 2




- Remove the screw in the CF compartment.

Step 3




- Open rubber Digital AV Out compartment flap
- Pry up the battery with the IFIXIT opening tool
- Carefully pull out the battery with two fingers
- Unscrew the two screws that are now visible

Step 4



- Start at the bottom, and carefully pull the casing off.
- The casing will pivot at the top
 - There are three catches the hold the back casing to the body
- ⓘ You may have to pull with some force. The rear panel will make a snapping noise when it separates from the body.

Step 5



- The interior of the camera should look like this

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-24 08:44:24 PM.